


SKU ID-160

Indoor Sauna



SIZE(mm):1600*1200*2100

H E K L A

PREFACE

Thank you very much for purchasing our product.

Please read this manual carefully before assembling and save it afterwards. Please write down the control box serial number of the cabin as this number will be required in case of repair or order of spare parts.

ATTENTION

Installation and repair should only be done by a qualified electrician!

Check power supply rating and make sure the grounded outlet is correctly connected before installation.

Use original parts only. Do not share the outlet with any other appliances.

When not in use, turn off the cabin's power unit.

Locate your cabin indoors and on a flat, level and dry surface. A protective cover for the Sauna is required.

DANGER

Covering the heaters causes a fire hazard due to overheating. Do not cover the heaters !

Keep flammable or easily combustible materials/objects (eg.towels) away from the heater at all times.

Do not touch the heater during and shortly after use as a burning hazard exists due to hot parts.

The light bulb heats in use. If the bulb needs to be changed, unplug the cabin and let the bulb cool down before changing it.

Should the electrical connection get damaged, it must be replaced-either by the manufacturer or by a licensed electrician!

WARNING

If you suffer from illness or other health-related problems, especially heart conditions or circulatory disturbances or if you take medication, you should consult a doctor before using the Sauna.

Children and frail persons should never be in the cabin without supervision.

If you feel uncomfortable while using the Sauna, stop immediately and consult with your doctor.

Never go to a hot Sauna if you have taken alcohol, strong medicines or narcotics.

Technical data

Model	SKU ID-160
Cabin material	Thermo Aspen
Width	1600mm
Depth	1200mm
Height	2100mm
LED Voltage	AC100-240V

Hardware parts (variations possible)

											
Ø4x12	Ø4x35	Ø4x40	Ø4x50	Ø4x60	Ø3*16	Ø8x60					
12x	14x	38x	16x	2x	1x	2x	1x	4x	2x	14x	2x

ASSEMBLE INSTRUCTIONS

Assemble tips






Please remove transport packaging and inspect that your sauna cabin has been delivered complete and intact before beginning assemble.

A least 2 persons are required for assemble of the cabin.


Please check the countersink and hole diameter of the drill holes to avoid damaging the wood.


















The minimum room height required for installation is 2500mm





Tools








Assemble steps




①  x1 2100*1561*44	②  x1 2100*1163*44	③  x1 2100*1163*44	④  x1 2100*120*40	⑤  x1 2100*120*40	⑥  x1 1362*90*40
⑦  x1 1903*410*8	⑧  x1 1903*410*8	⑨  x1 1362*120*40	⑩  x1 1499*40*20	⑪  x1 1547*1137*39	⑫  x1 200*60*10
⑬  x1 1499*90*40	⑭  x1 210*90*43	⑮  x1 1499*90*40	⑯  x1 1499*500*40	⑰  x2 1074*90*20	⑱  x3 340*90*20
⑲  x1 1074*90*20	⑳  x4 400*70*40	㉑  x1 1074*400*40	㉒  x1 1499*264*40	㉓  x1 1871*557*8	㉔  x1 625*40*40









4-Ø4*50MM




14

2-Ø4*60MM








15

(4-Ø4*12MM)x2



16





SERVICE

Use instructions

Drink plenty of drink water before and after use of the sauna cabin.

Dry yourself off completely.

After a heating period of an hour at the latest, the cabin should be switched off and a heating brake of at least 30 minutes should be taken.

Maintenance instructions

Clean the cabin with a damp cotton towel, dry with a clean dry towel.

Clean the glass with a window/glass cleaner and a soft cloth.

Do not pour water in the control panel or clean it with wet cloth. For cleaning purposes, use a cleaning cloth that has been only slightly moistened with a mild soapy solvent (dish detergent).

Do not use chemical detergents to clean the cabin.

Please fasten the screws of the bench once every three months, avoid the loose or drop off.

It is recommended to take a warm shower and relax after use.

Notes:
